

Current Cost EnviR Data Cable & Mac OSX 10.7 Driver Installation

Current Cost EnviR Data Cable & Mac OSX 10.7 -- Driver Installation

The original source for this document content can be found on Daniel Boorn's blog [Random Tech Projects](#).

If you are experiencing issues with the Prolific drivers not functioning correctly please follow the directions below.

Requirements:

- Current Cost EnviR Energy Monitor Device
- Current Cost USB Data Cable (Black/White) Version
- Mac OSX 10.7 (Lion)

Current Cost USB Data Cable Driver Installation

1. [Download](#) and Install Kext Utility.
2. [Download](#) osx-pl2303.kext.tgz (unarchive once downloaded)
3. Open Kext Utility and drag osx-pl2303.kext file into kext utility
4. Wait for Kext Utility to finish (should ask for password)
5. Restart computer
6. Open terminal and enter "ls /dev/tty.*" (without quotes)
7. Verify the "/dev/tty.PL2303-0000161D" or similar "/dev/tty.PL2303-xxxxxxx" is displayed